


LOOP TROTTER

AUDIO ENGINEERING


CONSOLE

OWNER'S MANUAL


CHANNELS MODULE




CHANNELS MODULE



MASTER MODULE



CHANNELS MODULE



500

ON

INSERT

500

ON

MIC

DAW

SOURCE

AUX 1

AUX 2

AUX 3

AUX 4

C

L

R

L-R

MUTE

SOLO

01

10

5

0

5

10

15

20

30

60

MIC/LINE INPUT

500 ON/OFF

500

INSERT ON/OFF

INSERT SEND

INSERT RETURN

500 ON/OFF

500

TO TAPE

TO TAPE OUTPUT

TO DAW

FROM DAW

DAW INPUT

PRE POST

MUTE

AUX 1-4

GROUP 1-4

L-R

AUX 1-4

SOLO


PAN

L-R



1-4

SOLO



MIC
DAW
SOURCE




STEREO INPUTS





GROUPS






GROUP
1-4 L-R SOLO



AUX MASTER




L-R OUTPUT






EXTERNAL INPUTS

MONITOR SOURCE - EXT





DAW INPUT

MONITOR SOURCE - DAW




MONITOR






CHANNELS MODULE


CONNECTIONS




TAPE OUTPUT




DAW INPUT




MIC/LINE INPUT



INSERT SEND




INSERT RETURN



MASTER MODULE

CONNECTIONS



DB-25 CONNECTOR

MAIN OUT / INS / DAW INPUT

- 1 - INSERT LEFT SEND
- 2 - INSERT LEFT RETURN
- 3 - INSERT RIGHT SEND
- 4 - INSERT RIGHT RETURN

- 5 - DAW INPUT LEFT
- 6 - DAW INPUT RIGHT

- 7 - MAIN OUTPUT LEFT
- 8 - MAIN OUTPUT RIGHT

EXT OUTPUT / AUX OUTPUT

- 1 - AUX 1 OUTPUT
- 2 - AUX 2 OUTPUT
- 3 - AUX 3 OUTPUT
- 4 - AUX 4 OUTPUT

- 5 - EXTERNAL OUTPUT LEFT
- 6 - EXTERNAL OUTPUT RIGHT

- 7 - STUDIO LOUDSPEAKER (SLS)
- 8 - STUDIO LISTEN

